



4657B POWER BRAKE BOOSTER MOUNTING BRACKET KIT

**This kit is designed for installing
a power brake booster on a non-power brake Corvette.
It fits 1963-1967 C2 & C3 Corvettes with original manual brakes.**

1-Remove the original master cylinder from the firewall.

2-Use the original master cylinder factory mounting studs to mount the power brake booster to the firewall. If the firewall has two holes and no studs, use two grade five 3/8"-16x 1"bolts to mount the booster to the firewall.

3-Before any drilling, verify that there are no wires or obstructions on the inside of the firewall.

4-Drill two 3/8" holes to mount the booster bracket arms. Carefully drill the holes using the bracket arm holes as a guide.

5-Once the two holes are drilled, position the bracket over the 3/8" holes and drill the two 3/16" rivet holes.

6-Install the bracket on the inside of the firewall, screw the 3/8" bolts into the bracket then secure the plate with the aluminum rivets. Verify that all fasteners are tight.

